



**Instruction Manual
Refrigerator**

BAMDF396SS

CONTENTS

1•Safety warnings

1•1•Warning	1
1•2•Meanings of safety warning symbols	2
1•3•Electricity related warnings	2
1•4•Warnings for using	3
1•5•Warnings for placement	3
1•6•Warnings for energy	4
1•7•Warnings for disposal	4

2 Proper use of the refrigerator

2•1•Placement	5
2•2•Leveling feet	6
2•3•Changing the Light	7
2•4•Starting	7
2•5•Energy saving tips	7

3 Structure and functions

3•1•Key components	8
3•2•Functions	9-10

4 Maintenance and care of the refrigerator

4•1•Overall cleaning	11
4•2•Cleaning of the track storage box	11
4•3•Cleaning of door tray	12
4•4•Defrosting	12
4•5•Out of operation	12

5•Trouble shooting

5•1•Trouble shooting	13
----------------------	----

1 Safety warnings

1.1 Warning



Warning: risk of fire / flammable materials

RECOMMENDATIONS :

This appliance is intended for domestic use only. any commercial or non domestic use will nullify the manufacturers warranty

For EN standard: This appliance can be used by children aged from 8 years and above and persons with reduce physical sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. (Europe directive optional)

For IEC standard: This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.)

Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

The appliance has to be unplugged after use and before carrying out user maintenance on the appliance.

WARNING :Risk of fire / flammable materials.

WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

WARNING: Do not damage the refrigerant circuit.

WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

WARNING: Please abandon the refrigerator according to local regulators for it use flammable blowing gas and refrigerant.

Do not use extension cords or ungrounded (two prong) adapters

DANGER Risk of child entrapment Before you throw away your old refrigerator or freezer:

-Take off the doors

-Leave the shelves in place so that children may not easily climb inside

The refrigerator must be disconnected from the source of electrical supply before attempting the installation of accessory

Refrigerant and cyclopentane foaming material used for the refrigerator are flammable.

Therefore, when the refrigerator is scraped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.

1 2 Meaning of safety warning symbols



Prohibition symbol

This is a prohibition symbol.
Any in compliance with instructions marked with this symbol may result in damage to the product or endanger the personal safety of the user.



Warning symbol

This is a warning symbol.
It is required to operate in strict observance of instructions marked with this symbol; or otherwise damage to the product or personal injury may be caused.




Note symbol


This is a cautioning symbol.
Instructions marked with this symbol require special caution. Insufficient caution may result in slight or moderate injury, or damage to the product.

This manual contains lots of important safety information which shall be observed by the users.

1 3 Electricity related warnings




- Do not pull the power cord when pulling the power plug of the refrigerator. Please firmly grasp the plug and pull out it from the socket directly.
- To ensure safe use, do not damage the power cord or use the power cord when it is damaged or worn.



- Please use a dedicated power socket and the power socket should not be shared with other electrical appliances. The power plug should be firmly contacted with the socket or else fires might be caused.
- Please ensure that the grounding electrode of the power socket is equipped with a reliable grounding line.




- Please turn off the valve of the leaking gas and then open the doors and windows in case of leakage of gas and other flammable gases. Do not unplug the refrigerator and other electrical appliances considering that spark may cause a fire.



- Do not use electrical appliances on the top of the appliance, unless they are of the type recommended by the manufacturer.

1.4 Warnings for using




- Do not arbitrarily disassemble or reconstruct the refrigerator, nor damage the refrigerant circuit; maintenance of the appliance must be conducted by a specialist
- Damaged power cord must be replaced by the manufacturer, its maintenance department or related professionals in order to avoid danger.



- The gaps between refrigerator doors and between doors and refrigerator body are small, to avoid injury please do not put your fingers in in these areas. Please close the doors gently to avoid causing items inside to fall.
- To avoid frost bite, please do not handle food or containers in the freezer section whilst your hands are wet.




- To avoid suffocation or injury, do not allow children to climb into your refrigerator.




- Do not place heavy objects on top of your refrigerator as they may be disturbed and fall causing injuries during door open and closing.
- Please pull out the plug in case of power failure or cleaning. Do not connect the refrigerator to power supply within five minutes to prevent damages to the compressor due to successive starts.


1.5 Warnings for placement of items



- Do not put flammable, explosive, volatile and highly corrosive items in the refrigerator to prevent damages to the product or fire accidents.
- Do not place flammable items near the refrigerator to avoid fires.



- The refrigerator is intended for household use, such as storage of foods; it shall not be used for other purposes, such as storage of blood, drugs or biological products, etc.



- Do not store beer, beverage or other fluid contained in bottles or enclosed containers in the freezing chamber of the refrigerator; otherwise the bottles or enclosed containers may crack due to freezing to cause damages.

1.6 Warnings for energy

- 1) Refrigerating appliances might not operate consistently (possibility of defrosting of contents or temperature becoming too warm in the frozen food compartment) when sited for an extended period of time below the cold end of the range of temperatures for which the refrigerating appliance is designed.
- 2) Effervescent drinks should not be stored in food freezer compartments or cabinets or in low-temperature compartments or cabinets, and that some products such as water ices should not be consumed too cold;
- 3) Do not exceed the storage time(s) recommended by the food manufacturers for any kind of food and particularly for commercially quick-frozen food in food-freezer and frozen-food storage compartments or cabinets;
- 4) When defrosting your appliance take care not to allow any existing food to rise in temperature. e.g. wrap in several layers of newspaper to insulate.
- 5) For doors or lids fitted with locks and keys, the keys should be kept out of the reach of children and not in the vicinity of the refrigerating appliance, in order to prevent children from being locked inside

1.7 Warnings for disposal

Refrigerant and cyclopentane foaming material used for the refrigerator are flammable. Therefore, when the refrigerator is scrapped, it should be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.



When the refrigerator is scrapped, disassemble the doors, and remove gasket of door and shelves; put the doors and shelves in a proper place, so as to prevent trapping of any child.




Correct Disposal of this product :


This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

2 Proper use of refrigerators


2 1 Placement




- Before use, remove all packing materials, including bottom cushions, foam pads and tapes inside of the refrigerator; tear off the protective film on the doors and the refrigerator body.



- Keep away from heat and avoid direct sunlight. Do not place the freezer in moist or watery places to prevent rust or reduction of insulating effect.
- Do not spray or wash the refrigerator; do not put the refrigerator in moist places easy to be splashed with water so as not to affect the electrical insulation properties of the refrigerator.



- Your refrigerator should be situated in a well ventilated indoor area, not subject to extreme temperatures. the ground shall be flat, and sturdy (rotate left or right to adjust the wheel for leveling if unstable).




- The top space of the refrigerator shall be greater than 30cm, and The refrigerator should be placed against a wall with a free distance more than 10cm to facilitate heat dissipation.

2 2 Leveling feet

1) Precautions before operation

Before operation of accessories, it shall be ensured that the refrigerator is disconnected from power. Before adjusting the leveling feet, precautions shall be taken to prevent any personal injury.

2) Schematic diagram of the leveling feet



(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)


3) Adjusting procedures:

- a. Turn the feet clockwise to raise the refrigerator;
- b. Turn the feet counterclockwise to lower the refrigerator;
- c. Adjust the right and left feet based on the procedures above to a horizontal level.


2.3 Changing the Light

Any replacement or maintenance of the LED lamps is intended to be made by the manufacturer, its service agent or similar qualified person.

2.4 Starting



- Before initial start, keep the refrigerator still for half an hour before connecting it to power supply.
- Before putting any fresh or frozen foods, the refrigerator shall have run for 2-3 hours, or for above 4 hours in summer when the ambient temperature is high.




- Leave enough space for convenient opening of the doors and drawers.
- The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor

2.5 Energy saving tips

- The appliance should be located in the coolest area of the room, away from heat producing appliances or heating ducts, and out of direct sunlight.
- Let hot foods cool to room temperature before placing in the appliance. Overloading the appliance forces the compressor to run longer. Foods that freeze too slowly may lose quality, or spoil.
- Be sure to wrap foods properly, and wipe containers dry before placing them in the appliance. This cuts down on frost build-up inside the appliance.
- Appliance storage bin should not be lined with aluminum foil, wax paper, or paper toweling. Liners interfere with cold air circulation, making the appliance less efficient.
- Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

3 Structure and functions

3.1 Key components



(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

Refrigerating chamber

- The Refrigerating Chamber is suitable for storage of a variety of fruits, vegetables, beverages and other food consumed in the short term.
- Cooking foods shall not be put in the refrigerating chamber until cooled to room temperature.
- Foods are recommended to be sealed up before putting into the refrigerator.
- The glass shelves can be adjusted up or down for a reasonable amount of storage space and easy use.

Freezing chamber

- The low temperature freezing chamber may keep food fresh for a long time and it is mainly used to store frozen foods and making ice.
- The freezing chamber is suitable for storage of meat, fish, rice balls and other foods not to be consumed in short term.
- Chunks of meat are preferably to be divided into small pieces for easy access. Please note: Food should be consumed withing the guidelines given by the food producer.

Preservation drawer


Adjust preservation drawer adjustment device to change temperature in preservation drawer. The drawer is divided into three sections: High, Mid, Low (from left to right).



- High: This section is used for storing all kinds of vegetables and fruits to keep their moisture and freshness.
- Mid: This section is used for storing instant food, the food will be kept extreme cold, but not frozen. This is the best choice for fresh instant food.
- Low: This section is designed for storing seafood and meat, keeping food fresh under 0°C for a short term and locking nutrition in. It's recommended to set the temperature of freezer under 2°C for a better effect.

Note: Storage of too much food during operation after the initial connection to power may adversely affect the freezing effect of the refrigerator. Foods stored should not block the air outlet; or otherwise the freezing effect will also be adversely affected.

3 . 2 Functions



(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

1. Display screen:

refrigerating icon	OFF icon	temperature display area	super refrigerating icon
freezing icon	lock/unlock icon	vacation icon	super freezing icon

2. Operation button:

A. refrigerating button	B. freezing button
C. mode button	D. lock/unlock button



3 Operation instructions

1) Display

The first time the power was turned on for the refrigerator, the display screen will total display for 3 seconds. Meanwhile the starting up bell rings and then the screen enters the normal display of operation.

The first time for using the refrigerator, the default temperature of the refrigerating chamber and freezing chamber is 5 °C / -18 °C respectively.

When an error occurs, the display shows the error code (see next page); during normal operation, the display shows the set temperature of the refrigerating chamber or freezing chamber.


Under normal circumstances, if there is no operation on the display panel or door opening action within 30s, then the display shows the lock state , and the display goes out after the lock state  continued for 30s.

2) Lock /unlock


In the unlocked state, continue to press the lock button  for 3 seconds, enter the lock state. The logo  lights up and buzzer sounds, it means the display panel is locked, at this time, button operation cannot be implemented;

In the locked state, continue to press the lock button  for 3 seconds, enter the unlocked state. The logo  goes out and buzzer sounds, it means the display panel is unlocked, at this time, button operation can be implemented;


3) Temperature setting of refrigerating chamber






Press the temperature adjusting button of the refrigerating chamber  REF.TEMP to change the setting temperature of the refrigerating chamber, and then each time a press of the temperature adjusting button of the refrigerating chamber, the temperature will be reduced 1 °C; The temperature setting range for the refrigerating chamber is 2~8 °C. When the temperature is 2 °C, press the button again, and the temperature of the refrigerating chamber will be set at 8 °C, and it circulates accordingly.


4) Temperature setting of freezing chamber


Press temperature adjusting button of the freezing chamber  FRZ.TEMP to change the setting temperature of freezing chamber and then each time a press of temperature adjusting button of the freezing chamber, the temperature will be reduced 1 °C; The temperature setting range for freezing chamber is -24 °C ~ -16 °C. When the temperature is -24 °C, press the button again, and the temperature of freezing chamber will be set at -16 °C, and it circulates again and again.


5) Mode setting


Press mode button  MODE to select different control mode. Control mode is cycled according to the following regulation:




Super refrigerating  super freezing  super refrigerating and super freezing  vacation  none super refrigerating .


When super refrigerating mode  is set, temperature of refrigerating chamber will automatically set at 2 °C;


Exit super refrigerating  mode, temperature of refrigerating chamber will automatically return back to temperature set before super refrigerating mode.

When super freezing mode  is set, temperature of freezing chamber will automatically set at -24 °C;

Exit super freezing  mode, temperature of freezing chamber will automatically return back to temperature set before super freezing mode. Time setting of super freezing:

After setting the super freezing  mode, long press the freezing temperature adjusting button  FRZ.TEMP for 3 seconds, the display shows "48", which means that time of super freezing has been set at 48 hours. And press freezing temperature adjusting button , the display shows "6", which means that time of super freezing has been set at 6 hours. when the time arrives, it will exit the super refrigerating mode automatically.

After setting the super refrigerating  mode, The super refrigerating time setting is 2.5 hours by acquiescence, and the super refrigerating mode will exit automatically when the time arrives.

When vacation mode  is set, temperature of freezing chamber will be automatically set at -18 °C; the temperature of refrigerating chamber is turned off, and the icon (OFF) shines.

6) Storage upon power failure

In case of power failure, the instant working state will be locked and maintained until re-electrification.

7) Opening warning and alarm control

When the refrigerator doors get open, the opening music will play. If the door is not closed in two minutes, the buzzer will sound once every minute until the door is closed. Press any one button to stop the buzzer alarm.

8) Fault indication

The following warnings appearing on the display indicate corresponding faults of the refrigerator. Though the refrigerator may still have cold storage function with the following faults, the user shall contact a maintenance specialist for maintenance, so as to ensure optimized operation of the appliance.


Error code	Error description	Error code	Error description
E1	Temperature sensor failure of refrigerating chamber	E6	Communication error
E2	Temperature sensor failure of freezing chamber	E7	Failure of ambient temperature sensor
E4	Failure of defrosting sensor in refrigerating chamber	EH	Failure of humidity sensor
E5	Failure of defrosting sensor in freezing chamber		

4. Maintenance and care of the appliance

4.1 Overall cleaning

- Dusts behind the refrigerator and on the ground shall be timely cleaned to improve the cooling effect and energy saving. The interior of the refrigerator should be cleaned regularly to avoid odor. Soft towels or sponge dipped in water and non-corrosive neutral detergents are suggested for cleaning. The freezer of shall be finally cleaned with clean water and dry cloth. Open the door for natural drying before the power is turned on.
- Do not use hard brushes, clean steel balls, wire brushes, abrasives, such as toothpastes, organic solvents (such as alcohol, acetone, banana oil, etc.), boiling water, acid or alkaline items clean refrigerator considering that this may damage the fridge surface and interior.
- Do not rinse with water so as not to affect the electrical insulation properties.




 Please unplug the refrigerator for defrost and cleaning.)

4.2 Cleaning of freezer drawer partition



1) Remove partition:

Pull out partition, pressing inner wall of drawer with one hand and pulling the middle partition out with another hand.




2) Install partition:

Press partition slowly down the slot until you hear a click. There are two slots in the drawer for your option.



(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

4 3 Cleaning of door tray



(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

Cleaning steps:

- a、 in order to conveniently take off tray, punch the bottom of right part of tray for several times and again punch the bottom of left part of tray for several times, as shown in the figure;
- b、 tray can be smoothly taken off after it has been loosened. ;

4 4 Defrosting

- The refrigerator is made based on the air-cooling principle and thus has automatic defrosting function. Frost formed due to change of season or temperature may also be manually removed by disconnection of the appliance from power supply or by wiping with a dry towel.

4 5 Out of operation

- Power failure: In case of power failure, even if it is in summer, foods inside the appliance can be kept for several hours; during the power failure, the times of door opening should be reduced, and no more fresh food shall be put into the appliance.
- Long-time nonuse: The appliance shall be unplugged and then cleaned; then the doors are left open to prevent odor.
- Moving: Before the refrigerator is moved, take all objects inside out, fix the glass partitions, vegetable holder, freezing chamber drawers and etc. with tape, and tighten the leveling feet; close the doors and fix them with tape. During moving, the appliance shall not be laid upside down or horizontally, or be vibrated; the inclination during movement shall be no more than 45°.



The appliance shall run continuously once it is started. Generally, the operation of the appliance shall not be interrupted; otherwise the service life may be impaired

5 Trouble shooting

5 1You may try to solve the following simple problems by yourself.
If them cannot be solved, please contact the after-sales department.

Failed operation	<p>Check whether the appliance is connected to power or whether the plug is in well contact</p> <p>Check whether the voltage is too low</p> <p>Check whether there is a power failure or partial circuits have tripped</p>
Odor	<p>Odorous foods shall be tightly wrapped</p> <p>Check whether there is any rotten food</p> <p>Clean the inside of the refrigerator</p>
Long-time operation of the compressor	<p>Long operation of the refrigerator is normal in summer when the ambient temperature is high</p> <p>It is not suggestible having too much food in the appliance at the same time</p> <p>Food shall get cool before being put into the appliance</p> <p>The doors are opened too frequently</p>
Light fails to get lit	<p>Check whether the refrigerator is connected to power supply and whether the illuminating light is damaged</p> <p>Have the light replaced by a specialist</p>
Doors cannot be properly closed	<p>There may be too much food in the refrigerator</p> <p>The refrigerator is tilted</p>
Loud noise	<p>Check whether the floor is level and whether the refrigerator is placed in stable locationy</p> <p>Check whether accessories are placed at proper locations</p>
Door seal fails to be tight	<p>Remove foreign matters on the door seal</p> <p>Heat the door seal and then cool it for restoration (or blow it with an electrical drier or use a hot towel for heating)</p>
Water pan overflows	<p>There is too much food in the chamber or food stored contains too much water,resulting in heavy defrosting</p> <p>The doors are not closed properly, resulting in frosting due to entry of air and increased water due to defrosting</p>
Hot housing	<p>Heat dissipation of the built-in condenser via the housing, which is normal</p> <p>The housing may become hot due to high ambient temperature, storage of too much food or lack of ventilation.</p> <p>Please ensure enough ventilation is provided.</p>
Surface condensation	<p>Condensation on the exterior surface and door seals of the refrigerator is normal when the ambient humidity is too high. Just wipe the condensate with a clean towel.</p>
Abnormal noise	<p>Buzz: The compressor may produce buzzes during operation, and the buzzes are loud particularly upon start or stop. This is normal.</p> <p>Creak: Refrigerant flowing inside of the appliance may produce creak, which is normal.</p>



Your Belling Appliance is guaranteed against breakdown for an initial period of 12 months from date of purchase (for guarantee conditions please refer to your instruction booklet)

Your standard one year guarantee is extended for an additional 12 months when you register the product within 28 days of purchase with Glen Dimplex Ireland. If you do not register the product with Dimpco within 28 days, your product is guaranteed for 1 year.

To activate your 2 year guarantee please register with us online at www.glendimplexireland.com and click on the Warranty link.

Or call our customer registration line: **00353 1 8428222**

Note: Each qualifying product needs to be registered with Dimpco individually.

Please note that the 2 year guarantee is only available in the Republic of Ireland.

It is important to retain the retailer's receipt as proof of purchase.

Please quote the following information if the product develops a fault. These numbers can be found on the product.

Model no. _____

Serial No. _____

If you require a service callout please call us at 00353 1 8428222 or contact us at:
www.glendimplexireland.com/contact or email us at serviceireland@glendimplex.com

You may be asked to return a copy of proof of purchase before any warranty service is carried out.

Please note: Failure to use the appliance in accordance with the manufacturer's instructions and recommendations will invalidate your warranty.