



Instruction Manual

REFRIGERATOR

MODEL: BL112WH

General

This appliance is designed for use in domestic situations only. Use in commercial applications will invalidate the warranty.

It is not suitable for refrigerating medicines where stable and exact temperatures are maintenance is critical.

General Warranty Terms

1. That it is used for domestic purposes and in a residential address only.
2. That it has been installed and used in accordance with the instruction manual and any separate installation instructions provided by Glen Dimplex Ireland.
3. That it has been properly connected to mains supplied electricity, gas and water and drainage as appropriate. In the case of gas appliances,
4. That the appliance has not been subject to misuse or accident, nor been repaired or modified other than by our own Service Agent (except Gas LPG conversion – see above).
5. Where deemed necessary by Glen Dimplex Ireland to exchange an appliance within the guarantee period, the new appliance will be covered by the original guarantee period and will not be subject to a new guarantee.
6. This guarantee is not transferable and only relates to the original purchaser of this appliance/appliances.
7. That the appliance is not used for Hire purposes.

This guarantee excludes and does not cover service calls to:

1. Correct the installation of the appliance.
2. Remove or re-install an integrated appliance prior to and after an engineer's visit for any repair.
3. Repair any second hand appliances or those used by several people in communal areas.
4. Correct normal wear and tear that can be reasonably expected from an appliance based on age and use.
5. Instruct the user in the correct operation of the appliance.
6. Replace house mains fuses or correct house wiring, plumbing, drainage or gas supply.
7. Replace or repair any cosmetic or consumable parts such as bulbs, plugs, fuses, cables, filters and attachments, control knobs, handles, glass and wire shelves, rubber hoses, plastic door shelves and any accessories for example Oven baking trays and shelves. These include any parts which have become worn, discoloured or damaged, including damage by incorrect use or cleaning.
8. Repair an appliance due to the effects of lime-scale, mould, dirt, grease, spillages and odours.
9. Unblock the pump of a washing machine or dishwasher.
10. Repair damage caused by flood, lightning, electrical shock or surge, storm, extreme temperature, explosion, impact, corrosion, theft or attempted theft,
11. Deal with any noise, vibration or steam resulting from the normal operation of the appliance. These include periodic start and running of fans, flow and drain pump, steam from a washer, dryer, dishwasher and oven.
12. Reverse door hinges on cooling appliances.
13. Repair hob burner damage caused by using unsuitable cooking utensils pans/pots

14. Repair or replace any metal or glass ceramic hobs because of chips, scratches, cracks or damages, resulting from unknown causes or abrasive cleaning and cleaning agents, improper use of utensils, improper shape or uneven base of utensils or foreign particles in between the utensil and hob surface.

Glen Dimplex Ireland will not be liable for any consequential loss, or loss of use whilst the machine is being repaired.

Important: Glen Dimplex Ireland reserves the right to 1) charge the Buyer the entire cost of a service call and any spares, should the Buyer's service call include any of the above defined instances and 2) Inspect the appliance prior to any action taken for an exchange / replacement.

Installation Instructions

1. Do not tilt your refrigerator more than 45° from upright whilst moving it. Do not lift by the door or door handle as this may damage the unit, and affect its performance.
2. To ensure proper ventilation for your refrigerator please ensure there is at least 25mm free space at the back and sides of it, and 30mm from the top of it to any counter top or similar surface.
3. Do not install your refrigerator near a heat source or in direct sunlight.
4. Your refrigerator should not be installed in a shed or outhouse where it may be subject to very cold temperatures.
5. Do not install your refrigerator in an area of high humidity as this may interfere with proper sealing of the door and will the possibility of rust etc.
6. The refrigerator should be installed on a firm level surface. The feet are adjustable to allow for it to be levelled.
7. If your refrigerator has been transported on its side, please allow 4 hours before plugging it in to allow the oil to settle back into the compressor.

Safety Precautions

**WARNING: DO NOT REMOVE THE EARTH PIN
DO NOT USE A MULTIPLUG ADAPTOR
DO NOT USE AN EXTENSION LEAD**

1. Ensure the unit is plugged into a power supply of 220 ~ 240 Volt / 50Hz and is properly earthed. Only a 13amp Fuse should be used in the plug top.
2. Before carrying out any maintenance or installation work, please ensure the unit is disconnected from the power supply.
3. Do not store any flammable substances in your refrigerator.
4. Avoid splashing water on your refrigerator.
5. If for any reason you unplug your refrigerator, please wait ten minutes before reconnecting the power. This will protect the compressor.
6. If for any reason the gas should leak from the refrigeration system, please do not remove or re-insert the power plug as it may spark and as the gas is flammable it may cause a small fire. The quantity of gas in your refrigerator is very small and will dissipate very quickly.

Instructions for Use

1. When using your refrigerator for the first time, please run it with no food until it reaches the desired temperature. This can take 2 - 3 hours depending on the ambient temperature of the room it's situated in.
2. The temperature of the refrigerator can be adjusted by turning the thermostat dial up or down. A medium setting is usually best. In very warm weather the ambient temperature will be higher so the dial may need to be adjusted to compensate.

Points to note

1. Each time food is added, or the more the door is opened etc., the refrigerator will use more energy to compensate. Therefore it is best to not overload it and to avoid unnecessary opening / closing of the door.
2. During a power cut, temperature will be maintained best if the door remains closed as long as possible.
3. Please do not store heavy or sharp objects in your refrigerator.
4. Freestanding refrigerators should not be built into cabinets. This will severely impair their operation and will nullify your warranty.

Maintenance

1. Do not clean your refrigerator with abrasive cream cleaners, chemicals, products containing alcohol or bleach etc. as they may damage the surfaces. It should only be cleaned with warm water and a cloth.
2. The door gasket should be cleaned regularly to allow it to seal properly.
3. If your refrigerator is not in use for a long period of time please unplug it, clean and dry it and close the door tightly

The following issues are not failures and may show in normal use

1. A sound of flowing water or gurgling. This is normal, especially in newer refrigerators. This sound may disappear and generally over time will become less noticeable.
2. Condensation. In warm weather or a very warm room surface condensation is natural and may be just wiped away unless excessive.
3. The compressor is hot to touch. This is normal while in use.

Before calling for service:

Issue	Possible Cause
Not Cooling	<ol style="list-style-type: none">1. Check that there is plug is properly inserted.2. Check that there is power in the relevant socket.
Insufficient Cooling	<ol style="list-style-type: none">1. Is the thermostat setting appropriate?2. Is there enough ventilation around the unit?3. Is the unit installed in direct sunlight?4. Check that the unit is not over stocked.5. Has the door been opened too frequently or for a long time?
Food in the fridge compartment is frozen	<ol style="list-style-type: none">1. Is the thermostat setting appropriate?2. Is the unit over stocked?
The unit is noisy	<ol style="list-style-type: none">1. Is the unit on a firm level surface?2. Have the levelling feet been adjusted?
The Compressor runs constantly	<ol style="list-style-type: none">1. Is the food evenly distributed around the shelves?2. Avoid over stocking one shelf and under stocking another.3. Is the door left open too long or too frequently.4. Check that the door seal is intact.

If you have checked all of the above and still need assistance please contact the service agent using the contact details in the rear of this booklet.

General tips for household refrigerators

Try not to open the door too often, especially when the weather is wet and hot. Once you open the door, try to close it as soon as possible.

Every now and then check if the appliance is sufficiently ventilated (adequate air circulation behind the appliance).

For household refrigerating appliances, in normal temperature conditions, please set the thermostat at the middle setting.

Before loading the appliance with packages of fresh foods, make sure they are cooled to ambient room temperature.

Ice and frost layer increase energy consumption, so do clean the appliance as soon as the layer is 3-5 mm thick where appropriate.

If your unit has an external condenser, the rear wall should be always clean, free of dust or any impurities.

Always consider instructions stated in sections Positioning and Energy Saving Tips, otherwise the energy consumption is substantially higher.



条码仅供参考，实际扫码按正确的14位新物料编码生成
(文字部份固定不变，前后无空格，黑色印刷)
码制与其它要求按冰箱事业部最新公文要求

SIZE:60*20mm

XXXXXXXXXXXXXXXX:14位新物料编码