

NO.	Spare part	English description	qty
1	12831000004432	cabinet	1
2	12131000005190	BFZ32WH Top hinge cover	1
3	11303309000081	BFZ32WH Self Tapping Screw	4
4	12231000006953	BFZ32WH Top hinge cover	1
5	12831000005624	BFZ32WH Top hinge plate	1
6	12831000003326	BFZ32WH Door	1
7	12131000010744	BFZ32WH Gasket	1
8	11303125000660	BFZ32WH Top hinge plate	2
9	12131000001936	BFZ32WH Door liner	1
10	12131000003652	BFZ32WH Thermostat knob	1
11	12231000009483	BFZ32WH Bottom hinge	1
12	11300914000022	BFZ32WH Screw	4
13	12131000001018	BFZ32WH Adjustable leg	1
14	12131000001004	BFZ32WH Fixed leg	1
15	12931000000860	BFZ32WH Shelf	1
16	12131000004312	BFZ32WH Water plate	1
17	17431000001379	BFZ32WH Thermostat	1
18	12131000001142	BFZ32WH Thermostat box	1
19	11303309000081	BFZ32WH Self Tapping Screw	4
20	11300914000022	BFZ32WH Screw	2
21	12231000005872	BFZ32WH Compressor base	1
22	17431000000091	BFZ32WH Power cord	1
23	11101010000460	BFZ32WH compressor	1
24		BFZ32WH Overload Protec	1
25		BFZ32WH BFZ32WH PTC	1
26		Relay cover	1
27		Relay Band	1

