

No.	Part Code	Description of Spare Part	Qty
1	20122020369	Top cover	1
2	20122020150	Screw cover for top cover	4
3	20122990139	Egg tray	1
5	2301400017	Upper door hinge	1
6	2501100002	Door Switch	1
7	20122990103	Ice cube tray	1
9.1	3050400021	LED light assembly	1
9.2	3040200017	Thermostat	1
9.3	2207100030	Thermostat knob	1
14	20101021489	Upper door	1
14.1	3020400067	Upper door gasket	1
14.2	20122090004	Right limit block,upper door	1
14.3	20122090010	Left limit block,upper door	1
18	20122050591	Door rack,upper	2
19	20122050617	Door rack,lower	1
20	2106100062	Shelf of refrigerator chamber	2
21	3040300024	Evaperator of freezer	1
22	3040500011	Drier filter	1
23	2106120068	Cover of crisper drawer	1
24	20122990044	Drain pan	1
28	3040600005	Process tube	1
29	3040100122	Compressor	1
31	3050200094	Earthing wire of compressor	1
32	3031400116	Middle door hinge	1
33	20105050009	Compressor support base	1
34	3031400067	Lower door hinge	1
35	20122990604	Shelf breaker of freeze,middle	3
36	20122040035	Crisper drawer	2
37	3050100088	Power supply cord plug	1
38	20114070006	Connecting tube	1
39	3020500058	Shelf breaker of freeze,top	1
40	20101020215	Lower door	1
40.1	20122090159	Right aid-closer,lower door	1
40.2	20122090176	Left aid-closer,lower door	1
40.3	3020500069	Inner door gasket	1
40.4	3020400068	Lower door gasket	1
41	20122030097	Door drawer,lower	1
42	20122030037	Door drawer,middle	3
43	20122990023	Long leg	1
44	20122990016	Long adjust leg	1
300	2700500462	Trademark	1
301	3070101007	Carton	1

