

Item	Spare ID	Description	Qty
2	50121124001M	Compressor Base BR98WH	1
11	501111240003	top cover BR98WH	1
14	501108330013	top cover link button BR98WH	2
15	502905040039	Top hinge BR98WH	1
17	502408000009	Light switch BR98WH	1
18	50290504001N	hinge and adjustable foot BR98WH	1
20	501113040001	Adjustable Leg BR98WH	1
22	501110040006	Ice Box Door lock hook BR98WH	1
23	501122510023	Ice Box Door Handle BR98WH	1
24	501122510021	small door cover BR98WH	1
25	50111004000E	Ice Box door Gasket BR98WH	1
28	501110040005	Ice Box door Hinge BR98WH	1
29	501112040033	lamp shade BR98WH	1
30	501112040062	Thermostat box BR98WH	1
31	502410000087	lamp BR98WH	1
32	502409000051	lamp holder BR98WH	1
33	50240700001A	Thermostat BR98WH	1
34	50111244000D	Thermostat knob BR98WH	1
36	50360104000F	glass shelf BR98WH	1
37	503700140319	Ice Box door BR98WH	1
38	50360204001C	Vegetable Box Cover BR98WH	1
39	501111240032	Vegetable Box BR98WH	1
41	501112840001	washer BR98WH	1
42	501123110005	hinge shaft sleeve BR98WH	1
45	501111240007	Door Seal BR98WH	1
47	501111240006	door stopper BR98WH	1
49	501111240031	Upper Door Tray BR98WH	2
50	501111240030	Lower Door Tray BR98WH	1
51	503705040333	Cabinet BR98WH	1
52	503700140318	Door BR98WH	1

