


| No. | Part Code | Description of Spare Part | Qty |
|------|-------------|--|-----|
| 4 | 2301400038 | EURSBS427 Lower Door Hinge Left | 1 |
| 5.2 | 2107150009 | EURSBS427 Adjustable Foot | 1 |
| 5.3 | 3060100074 | EURSBS427 Screw Of M6X16 | 1 |
| 5.4 | 2208510016 | EURSBS427 Block Of Aid-Closer Lower | 1 |
| 8.2 | 2107150009 | EURSBS427 Adjustable Foot | 1 |
| 8.3 | 3060100074 | EURSBS427 Screw Of M6X16 | 1 |
| 8.4 | 2208510016 | EURSBS427 Block Of Aid-Closer Lower | 1 |
| 9 | 2301400037 | EURSBS427 Lower Door Hinge Right | 1 |
| 10 | 20122990488 | EURSBS427 Cover Of Return Air Inlet | 1 |
| 12 | 20122990629 | EURSBS427 Cover Of Temperature Head | 2 |
| 13 | 20122990493 | EURSBS427 Screw Cap | 2 |
| 14.1 | 2208500047 | EURSBS427 Fan Motor BShelfet | 1 |
| 14.2 | 2208500046 | EURSBS427 Front Cover Of Freezer Wind Tunnel Parts Upper | 1 |
| 14.3 | 2208500057 | EURSBS427 Front Cover Of Freezer Wind Tunnel Parts Lower | 1 |
| 14.4 | 2800100049 | EURSBS427 Sponge Of Freezer Wind Tunnel Parts Cover | 1 |
| 14.7 | 3059900040 | EURSBS427 Fan Motor | 1 |
| 21 | 2106120193 | EURSBS427 Cover Of Upper Drawer Left | 1 |
| 22 | 2207300185 | EURSBS427 Upper Drawer LH | 1 |
| 23 | 2207300186 | EURSBS427 Lower Drawer RH | 1 |
| 24 | 2106100166 | EURSBS427 Freezer Shelf | 3 |
| 25 | 2106120192 | EURSBS427 Crisper Cover Right | 1 |
| 26 | 2207400176 | EURSBS427 Crisper Drawer Upper RH | 1 |
| 27 | 2207400177 | EURSBS427 Crisper Drawer Lower LH | 1 |
| 28 | 2106100165 | EURSBS427 Fridge Shelf | 3 |
| 34 | 2207500435 | EURSBS427 Fridge Door Shelf | 3 |
| 43 | 2100250308 | EURSBS427 Fridge Door | 1 |
| 43.1 | 3020400232 | EURSBS427 Fridge Door Gasket | 1 |
| 43.2 | 2208100018 | EURSBS427 Collar Upper | 1 |
| 43.3 | 3039900184 | EURSBS427 Limit Line Iron | 1 |
| 43.4 | 2208510015 | EURSBS427 Block Of Aid-Closer Upper | 1 |
| 53.1 | 2208100433 | EURSBS427 Decorative Plate Of Refrigerator Wind Tunnel Parts | 1 |
| 53.2 | 2208500045 | EURSBS427 Front Cover Of Refrigerator Wind Tunnel Parts | 1 |
| 53.3 | 2701000188 | EURSBS427 Refrigerator Wind Foam Parts Front | 1 |
| 53.4 | 2501100018 | EURSBS427 Damper Motor Of Refrigerator Wind | 1 |
| 53.5 | 2701000189 | EURSBS427 Refrigerator Wind Foam Parts Back | 1 |
| 53.6 | 2800100048 | EURSBS427 Sponge Of Air Inlet | 1 |
| 53.7 | 2800100047 | EURSBS427 Sponge Of Air Outlet | 1 |
| 59 | 20122990482 | EURSBS427 Cover Plate Of Fixed Seat | 1 |
| 60 | 20122010104 | EURSBS427 Cover Of Ceiling Light | 2 |
| 61 | 3050400018 | EURSBS427 Led Light Board | 2 |
| 62 | 2208100432 | EURSBS427 Cover Of Right Hinge Upper | 1 |
| 63 | 3031400215 | EURSBS427 Upper Door Hinge Right | 1 |
| 64 | 3031400214 | EURSBS427 Upper Door Hinge Left | 1 |
| 65 | 2208100431 | EURSBS427 Cover Of Left Hinge Upper | 1 |
| 67 | 2500300107 | EURSBS427 PCB | 1 |
| 68 | 3039900180 | EURSBS427 Cover Of Control Board | 1 |
| 69 | 20122990103 | EURSBS427 Ice Cube Tray | 1 |
| 70 | 20122990140 | EURSBS427 Egg Tray | 1 |
| 72 | 2207500436 | EURSBS427 Freezer Door Shelf | 4 |
| 73 | 2100250309 | EURSBS427 Freezer Door | 1 |
| 73.1 | 3020400231 | EURSBS427 Freezer Door Gasket | 1 |
| 73.2 | 2208100018 | EURSBS427 Collar Upper | 1 |
| 73.3 | 3039900184 | EURSBS427 Limit Line Iron | 1 |
| 73.4 | 2208510015 | EURSBS427 Block Of Aid-Closer Upper | 1 |
| 75 | 2500300060 | EURSBS427 Display PCB | 1 |



To order Spare Parts, please contact us at 01 8428222, or email at sparesireland@glendimplex.com

EURSBS427SS Parts List

Spare Parts are stored in our Ireland warehouse, and are shipped with 48 hour courier

| | | | |
|------|-------------|---------------------------------------|---|
| 76 | 2208100106 | EURSBS427 Display Plastic Board | 1 |
| 77 | 2209100056 | EURSBS427 Display Panel | 1 |
| 78 | 2207700087 | EURSBS427 Drain Pan | 1 |
| 79 | 2402400019 | EURSBS427 Evaporative Condenser | 1 |
| 80 | 3020600065 | EURSBS427 Drain Pipe | 1 |
| 82 | 2107100005 | EURSBS427 Compressor Base Support | 1 |
| 83 | 3050100096 | EURSBS427 Power Supply Cord Plug | 1 |
| 85 | 20114070006 | EURSBS427 Connecting Tube | 1 |
| 86 | 3040500022 | EURSBS427 Drier Filter | 1 |
| 87 | 2400100107 | EURSBS427 Compressor | 1 |
| 91 | 3050200094 | EURSBS427 Earthing Wire Of Compressor | 1 |
| 92 | 3040600005 | EURSBS427 Process Tube | 1 |
| 93 | 3050200155 | EURSBS427 Temperature Sensor | 1 |
| 94.1 | 3040300056 | EURSBS427 Fin Evaperator | 1 |
| 94.2 | 3071000186 | EURSBS427 Foam Of Fin Evaperator | 2 |
| 95 | 3050700013 | EURSBS427 Frost Heater & Fuse | 1 |
| 97 | 3039900181 | EURSBS427 Fixed Slot Of Heater | 1 |
| 99 | 2501100017 | EURSBS427 Door Switch | 2 |
| 300 | 2700500461 | EURSBS427 Trademark | 1 |
| 301 | 2700104771 | EURSBS427 Carton | 1 |