

# GLEN DIMPLEX IRELAND

---


Customer Support | Toshiba & Walker Products

## TV Fuse Replacement Guide

### **Important Safety Advice:**

Switch off the TV and unplug it from the wall socket before starting.

1. Unplug the TV from the socket
2. Open the plug fuse cover where indicated (Open here). Do not open the plug itself
3. Remove the fuse
4. Replace with a 5Amp fuse as supplied
5. Close the cover securely
6. Plug back in and test



Glen Dimplex Customer Support  
Phone: 01 8428222  
Email: [service.ie@glendimplex.com](mailto:service.ie@glendimplex.com)  
Website: [www.glendimplexireland.ie](http://www.glendimplexireland.ie)